Non-streak Glass Cleaner

- CLEANS GLASS WITH A STREAK FREE SPARKLING SHINE
- FOR USE ON WINDOWS AND ALL GLASS SURFACES
- NO BLOOMING OR CLOUDING OF GLASS AFTER USE
- EASY TO USE SIMPLY SPRAY ON AND WIPE OFF WITH A MICROFIBRE CLOTH

Enviromose Non Streaky Glass Cleaner has been developed over the last 5 years and this water based formulation uses the latest technology to give a streak free sparkle to glass surfaces. Unlike other formulations, surfaces cleaned with Enviromose Non Streaky Glass Cleaner stay clean without the blooming or clouding that can form following cleaning with other products.

BENEFITS

- · Easy to use
- Non streaking
- · Labour saving
- Non blooming

APPLICATION

- · Shake well before use
- Use a hand-pumped sprayer
- Spray an even coat on the surface
- Leave for 30-40 seconds
- Wipe off excess with a dry, soft cotton cloth, kitchen towel or microfibre cloth

STORAGE

24 months from the date of manufacture in original unopened container in a clean, dry area. Do not store below 5°C.



HEALTH & SAFETY

- Keep out of reach of children.
- Wear protective gloves/protective clothing/eye protection/face protection.
- Do not get in eyes, on skin, or on clothing.
- Do not eat, drink or smoke when using this product.
- IF SWALLOWED: Immediately call a POISON CENTRE/doctor.
- IF ON SKIN: wash with plenty of soap and water, get medical advice/attention.
- IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing, get immediate medical advice/attention.

