# enviromose

# RESTORE

# **Wood Reviver**

An easy to use, highly effective wood reviver, to bring wood back to its natural warm tones, reversing damaged cause by weathering and UV.

Wood Reviver is a water based gel, used to refresh and restore both soft and hard wood back to their natural tone. Once treated the surface can be over-coated and refinished. Suitable for use on both smooth and roughly sawn wood.

# **Surface Preperation**

Brush away leaves/debris and remove surface coatings before treating. Wood Reviver may remove some surface coatings, however, if any remain please use a Sealer Remover to remove any sealers / paint which remains on the surface or an oil and grease remover to remove any remaining oils.

Do not use a pressure washer to clean the wood prior to using the product. Keep children and pets/animals away until cleaning process is complete and surface is dry. Do not apply in direct sunlight. Do not allow to come into contact with plants/shrubs or materials containing calcium carbonate eg, limestone/marble as damage may occur. Avoid contact with metal fixings as discolouration / damage may occur. If contact with metal fixings does occur remove immediately with a water using a damp cloth.

## How to use

Always test on a small hidden portion of the surface to be cleaned to check compatibility and performance/finish is acceptable before commencing with the whole area. DO NOT dilute, Wood Reviver is supplied ready to use.

- Dampen the wood before application
- Apply generously along the wood grain using a brush or roller to all exposed sides. Complete 2 metres at a time to avoid drying out
- If the product drys re-hydrate by spraying with water or wiping down with a dry cloth
- Leave the product to work for 15 30 minutes
- Agitate using a damp cloth or non-metal brush dampened with water
- Rinse the wood thoroughly to remove any remaining residue. Repeat the process as necessary
- The wood is now ready for sanding and applying wood preservative / top coat to prevent any further UV or Weather damage.

## Precautions for use

For Health & Safety instructions, first aid measures, spillages and disposal instructions, see separate Health & Safety Data Sheet (MSDS).

# Cleaning of equipment

Clean tools and equipment immediately after use with water. Always read safety instructions before use.



#### Perfect for use on

- Windows
- Sheds
- Fences
- Decking
- All outdoor wooden furniture

#### **Renefits**

- · Easy to use
- Restores the wood to its natural tones removing greying caused by UV rays and weathering
- Internal & external Use
- Safe on joints
- Fast acting
- Quick drying
- · Surfaces can be treated / painted

# Storage

Keep out of reach of children Keep in a dry place between 5°C and 30°C in the original container.

# **Product Characteristics**

Colour	Clear
Odour	Barely Perceptibe
Form	Liquid
Application Temperatures	Between 5°C and 30°C
Shelf Life	24 Months from the date of manufacture in the original unopened container - protect from frost

